AIRPORT DIAGRAM

AL-430 (FAA)

TUCSON INTL (TUS)
TUCSON, ARIZONA



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

ALL AIRCRAFT USE UPPER ANTENNA UNTIL AIRBORNE

AIRPORT DIAGRAM

TUCSON, ARIZONA
TUCSON INTL (TUS)

16035